



ETATRON

engineered excellence

AG-SELECT MENU GUIDE

PH CALIBRATION (SIMPLE MODE)

pH Calibration AG-Select B2

1. From main screen select OK and press the + button twice or until MENU CALIBRATION is shown.
2. Press OK button to go to CAL 1 – which is pH 7.
3. Place the pH electrode in the pH 7 buffer solution, mix slowly and wait until display stabilises. Use the PLUS and MINUS buttons to trim the reading to pH 7.00. Press OK
4. Clean the probe in fresh water.
5. For CAL 2 repeat the above process with either pH Buffer 4.00 or 9.00, use the PLUS and MINUS buttons to trim reading and select OK.

