



ETATRON

engineered excellence

AG-SELECT MENU

Etatron GB Ltd, Newlin Business Park, Exchange Road, Lincoln, LN6 3AB

Rx Calibration AG-Select B2

From main screen select OK and press PLUS button twice or until MENU CALIBRATION is shown

METER button selects either meter 1 or meter 2

Press OK button to go to 1st calibration point either 475 mV or 650 mV buffer solution can be used

Place clean Rx electrode into the buffer solution, mix slowly and then wait until display stabilises. Use the PLUS and MINUS buttons to trim the reading to match that of the buffer solution being used

Press OK button to confirm and to go to next calibration point 0 mV remove electrode and attach shorting plug as shown below. Alternatively connect external cylinder part to centre pin with length of wire



To get a true 0 point calibration a shorting plug should be used

